

1.7. Installation

Please note that the Rod End is not capable of receiving a thrust load indicated in Fig. 2.




Fig. 2 Examples of Installing the Rod End